

Kchibo KK-522 Operating Instructions

Radio design : (Please refer to the original picture in printed manual)

1. Led frequency indicator
2. Power switch
3. Time setting button
4. Frequency tuning switch
5. HOUR setting button
6. MIN setting button
7. Volume control
8. Alarm time setting button
9. Alarm on/off switch
10. AM button
11. FM button
12. LCD display
13. Antenna
14. Hand strap
15. Earphone plug
16. Battery compartment

LCD display : (Please refer to the picture in printed manual)

1. Frequency unit indicator(KHz)
2. Frequency unit indicator (MHz)
3. Time or Frequency display
4. Alarm function display
5. Alarm set display
6. P.M. display
7. FM display
8. AM display

Radio operations :

1. Press the FM button (11) to power on and receive FM radio channels.
2. Press the AM button (10) to power on and receive AM radio channels.
3. Turn the volume switch (7) to set the volume.
4. Turn the Frequency switch (4) to set the frequency.
5. The indicator (1) will light up when the correct frequency is tuned.
6. When you plug in the earphones(15), the speaker will automatically turn off.

7. Press the Power off button (2) to turn off the radio.

Time setting :

1. "12:00" will be displayed when batteries are installed.
2. Press and hold the "TIME SET" button (3) , at the same time press the "HOUR" (5) or "MIN" (6) button the set the right time.
3. When the radio is turned off (2), the present time will be displayed.
4. 12 hrs system was adopted. AM/PM will be displayed.

Alarm Time setting :

1. Under the time mode, press and hold "AL. DISP" button (8) , the AL will be displayed. Set the correct time with the "HOUR" (5) and "MIN" button.(6)
2. When the radio is on , press the "AL. DISP" button to display the set time.

Alarm function :

1. When the alarm time has been set, the radio shall be in time mode.
2. Press the AL ON/OFF button (9) to turn on the alarm function. The alarm icon will appear. When the set time comes, the radio will automatically turn on.
3. After you turn off the AL ON/OFF button (9), you can press the POWER OFF button to turn off the radio.