

Kchibo KK-523 Operating Instructions

Radio design : (Please refer to the original picture in printed manual)

1. Alarm ON/OFF button
2. MIN button
3. Frequency tuning switch
4. HOUR button
5. Power off button
6. Volume control
7. LCD Display
8. ALARM TIME SET button
9. TIME SET button
10. FM button
11. AM button
12. Antenna
13. Belt clip
14. Earphone plug
15. Battery compartment

LCD display : (Please refer to the picture in printed manual)

1. Frequency unit indicator(MHz)
2. Frequency unit indicator (KHz)
3. Time or Frequency display
4. Alarm function display
5. Alarm set display
6. P.M. display
7. FM display
8. AM display

Radio operations :

1. Press the FM button (10) to power on and receive FM radio channels.
2. Press the AM button (11) to power on and receive AM radio channels.
3. Turn the volume switch (6) to set the volume.
4. Turn the Frequency switch (3) to set the frequency.
5. When you plug in the earphones(14), the speaker will automatically turn off.
6. Press the Power off button (5) to turn off the radio.
7. Radio comes with removable belt clip for outdoor entertainment.

Time setting :

1. "12:00" will be displayed when batteries are installed.
2. Press and hold the "TIME SET" button (9) , at the same time press the "HOUR" (4) or "MIN" (2) button the set the right time.
3. When the radio is turned off (5), the present time will be displayed.
4. 12 hrs system was adopted. AM/PM will be displayed.

Alarm Time setting :

1. Under the time mode, press and hold "AL. SET" button (8) , the AL/SET will be displayed. Set the correct time with the "HOUR" (4) and "MIN" button.(2)
2. Press the "AL. SET" button to display the set time.

Alarm function :

1. When the alarm time has been set, the radio shall be in time mode.
2. Press the AL ON/OFF button (1) to turn on the alarm function. When the set time comes, the radio will automatically turn on.
3. After you turn off the AL ON/OFF button (1), you can press the POWER OFF button to turn off the radio.