



## Kchibo KK-528 User's Manual

### Picture Illustration



1. Night light	7. Min/Volume -
2. Mode	8. Hr/Volume +
3. Key Lock	9. Tuning switch
4. Sleep	10. Earphone jack
5. Power	11. Battery compartment
6. Band Selector	

### LCD Display



1. Time display	7. Volume indicator
2. FM indicator	8. Volume level

3. Reception	9. Alarm indicator
4. Frequency display	10. AM unit (KHz)
5. Key lock	11. Sleep
6. FM unit (MHz)	12. AM indicator

### **Radio Operation**

1. Press Power button (5) to switch on the radio.
2. Plug in earphones into the earphone jack (10).
3. Select the band by pressing the band selector (6).
4. Rotate the Tuning switch (9) to the desired station.
5. Press the Volume – (7) or Volume + (8) to set the volume. There are 16 steps of volume level.
6. You may press the Key lock (3) to prevent any accidental operation.
7. Press the night light button (1) for night operation. The light will stay on for about 10 seconds.

### **AM/FM Reception**

You may need to rotate the radio for better reception.

### **Time Setting**

1. 24 hr format was adopted by this unit.
2. “12:00” will be displayed when batteries are installed.
3. Under the time mode, press the “Mode” button (2) once, you will see the Time blink.
4. Within 3 seconds, press the Hr (8) and the Min(7) to set the right time.
5. You can also set the time under the radio mode by the same procedures.

### **Auto Power-on Setting**

1. Under the time mode, press the Mode button (2) twice, you will see the alarm icon blink.
2. Within 3 seconds, press the Hr (8) and the Min (7) to set the alarm time.
3. You can also set the time under the radio mode by the same procedures.
4. Radio will automatically turn on upon the preset time at the station you last shut off.

5. The radio will turn off after 90 minutes operation.

### **Sleep Function**

1. Under the time mode, press the Sleep button (4) can turn on the radio. The “Sleep” icon and “90” will be displayed.
2. Within 5 seconds, press the Sleep button (4) again to set different sleep time. The order of change will be 90-80-70-60-50-40-30-20-10-Normal Time( Sleep function off).
3. You can also turn on the sleep function under the radio mode.
4. If you would like to turn off the radio earlier, press the Power (5) button.

### **Specifications**

1. Frequency
  - FM : 87-108 MHz
  - AM : 526.50 – 1606.5 KHz
2. Sensitivity
  - FM  $\leq 20\mu\text{V}$
  - AM  $\leq 5\text{mV/m}$
3. Selectivity  $\leq 10\text{ dB}$
4. Power supply : 2 x AAA batteries
5. Earphone : 3.5mm 32 ohm
6. Measurement : 107 x 47 x 23 mm
7. Weight : 70g ( excluding batteries)