


Go-On 757 Wireless Headphones User's Manual

Picture illustration



Transmitter

1. Reception Led
2. Power Led
3. Microphone
4. Transmission channel switch
5. Microphone audio output
6. 3.5mm audio in
7. 12V DC input jack

Headphone

8. Power Led
9. Power switch
10. Battery Compartment
11. Tuning Led
12. Tuning knob
13. Volume control
14. Audio in (For use in wired mode)

Installation

1. Transmitter – Connect the AC adapter with the transmitter. Connect the microphone cable between the PC and the transmitter if you would like to have internet chat.
2. Receiver (Headphone) - Install the batteries into the headphone (2 x AAA).

Operation

1. Connect the audio source with the transmitter. You will see the Led light on when the signal is under transmission.
2. Turn on the headphone to receive the signals. Adjust the tuning knob (12) to get the best reception.
3. You may need to adjust the transmission channel (4) of the transmitter if the signal is interfered.

Specifications:

- 1) System: RF
- 2) Modulation: frequency modulation (FM)
- 3) Output : 10mW
- 4) Operation distance: >50 meters (360°)
- 5) S/N ratio: >60dB
- 6) Distortion: 1%THD
- 7) Frequency response: 30 ~ 20,000Hz
- 8) Power supply:
 - a) Transmitter: DC 12/120mA
 - b) Receiver: DC 3V (2 x 1.5V AAA batteries)